



Wireless IP Bird Box Camera

Model: 4901-18

Green[®]Backyard

Operation and Installation Manual

? Need More Help

<https://green-backyard.com/pages/help>
support@golbong.com



WELCOME	3
PRODUCT OVERVIEW.....	4
HARDWARE INSTALLATION	4
<i>Attach the External Power Adapter.....</i>	<i>4</i>
SMARTPHONE OR TABLET APPS.....	5
CONNECT THE CAMERA DIRECTLY WITH APP	5
CONNECT THE CAMERA TO YOUR HOME NETWORK.	7
LIVE VIEW INTERFACE	12
OPTIONAL1: HOW TO CHANGE THE VIDEO QUALITY TO ADAPT TO LOW BANDWIDTH NETWORK.	12
SET A PASSWORD FOR THE CAMERA.....	13
SAVING LIVE STREAM TO YOUR SMART PHONE.....	15
VIEW SNAPSHOT AT LOCAL FILES.....	16
PLAYBACK VIDEO ON TF MEMORY CARD (CAMERAS WITH MICROSD ONLY)	17
DOWNLOAD VIDEO FROM TF MEMORY CARD (CAMERAS WITH MICROSD ONLY).....	18
OPTIONAL RECEIVE THE IP SETTING FROM YOUR LOCAL NETWORK (DHCP).....	20
USING CMS5 FOR PC OR MAC	21
SYSTEM REQUIREMENTS	21
INSTALLING SOFTWARE	21
NETWORK CONNECTION AND SETTINGS	21
<i>Connect to IP Camera</i>	<i>21</i>
<i>Optional 1: How to add the cameras to CMS5 outside of LAN</i>	<i>23</i>
<i>Optional 2: How to configure the network setting of the camera manually.</i>	<i>24</i>
LIVE VIDEO	25
<i>Watch the live</i>	<i>25</i>
<i>Digital ZOOM</i>	<i>26</i>
<i>Activate the audio</i>	<i>27</i>
CHANGE THE PASSWORD OF THE CAMERA	27
RECORDING LIVE TO YOUR COMPUTER	28
PLAYBACK THE VIDEO ON YOUR COMPUTER	29
RECORDING LIVE TO TF MEMORY CARD (CAMERAS WITH MICROSD ONLY)	31
<i>Format TF memory card</i>	<i>31</i>
PLAYBACK THE VIDEO FROM TF MEMORY CARD (CAMERAS WITH MICROSD ONLY)	32
DOWNLOAD THE VIDEO TO YOUR COMPUTER HARD DRIVE (CAMERAS WITH MICROSD ONLY)	34
SETTING CAMERA PARAMETERS	35
INSTALLING A NEW FIRMWARE.....	36
WEB BROWSER CONNECTION	37
CHECKING YOUR WEB BROWSER SECURITY LEVEL.....	37
ACCESS THE CAMERA OVER INTERNET.....	40

Welcome

Thank you for purchasing GOLBONG WIFI Bird Box camera!

This user manual is designed to be a reference tool for the installation and operation of your WIFI Bird Box camera.

Here you can find information about the camera's features and functions, as well as information to aid in troubleshooting.

Many of the setup and installation sections below have corresponding videos on YouTube

To access the setup videos, please go to <https://www.youtube.com/golbongtoday>



For access to the quick start guide and other support information, go to <http://www.golbong.com/support.asp>

To contact GOLBONG support, please do one of the following:

- a. Visit <http://www.golbong.com/contact-us.asp> and use the email form
- b. or Email GOLBONG Customer Support: support@golbong.com

Important Security Warning



In order to keep your GOLBONG camera secure and prevent unauthorized access, please make sure to follow the steps below: Never use the default password for your camera. Always ensure that your

password is at least 8-10 characters long and contains a combination of lowercase characters, uppercase characters as well as numbers.

Product Overview



Hardware Installation

Attach the External Power Adapter


Connect the power adapter to the power connector on your camera, then plug the power adapter into a wall outlet



Smartphone or Tablet Apps

Connect the camera directly with app


1. Download "XMEYE" from apple store or google play




2. Power up the camera and wait for 2 minutes




3. Enter the WIFI setting of your smart phone. A new AP spot will appear.




4. Connect the new AP, fill in the password "1234567890"



5. Login the XMEYE, press the "Direct Login" at the right down on screen.



6. Click the camera list to watch the live.



Connect the camera to your home network.

1. Press once the inline reset button




2. The new AP should disappear on your smart phone's wifi setting. The camera was switch to "Network mode"



NOTE: If you still see the AP spot, disable-enable the "WLAN" on your smart phone.

NOTE: Press the reset button for 10 seconds can reboot the camera and return back to "AP" mode for smart phone directly connecting.


3. Click the “Cloud Login” on the XMEYE



NOTE: Click “Login Problem?” You can register a new account.



4. On the Device List page, click the “+” right-top on screen.



5. On the Add Device page, select the "Quick Configuration"




6. Fill in the password of your home router, and click both "Ensure the indicator" and "Device Operation"




NOTE: you can ignore the remark message, click it anyway.


7. Press "Deep Config"



NOTE: After pressing "Deep Config", the screen will display a sentence and click "yes"




8. Wait for 1 minute, a green cam icon  pop up on the screen. Click the icon to add the camera




NOTE: if you fill in the wrong password of your home router, you need to press the reset button for 10 seconds. Then return to the step "a".

9. Click the camera list to watch the live.




Live view interface

1. Click the camera name in the device list, the live view will display.



2. Press the square icon on the upper right corner to enlarge the video to full screen.




NOTE: The users can zoom in/out on the screen with fingers.

3. Click "SD/HD" to choose the video quality.


NOTE: "SD": standard definition; "HD": high definition.

Optional1: How to change the video quality to adapt to low bandwidth network.


1. In the Live Video page, click the Home icon 



2. Touch “Encode” in the menu



3. Adjust the main stream and the sub stream to adapt to your network bandwidth.




NOTE: higher frame rate and resolution require higher bandwidth

Set a Password for the Camera.

1. In the Live Video page, click the Home icon



2. In the Menu page, press the “Change password ”



3. Input old password and a new password. Click “Save”




NOTE: default password is blank.(No need)


4. Click return icon  to enter Device list



5. click the edit icon  , a new dialog pop up



6. Select “Edit”




7. Name the device, key in the new password. Click OK to save.



Device Name: PTZ camera
Serial Numb... 47b073491011d678
Username: admin
Password: Password(Default...
OK Cancel

Saving live stream to your smart phone

1. In Live Video page, press “camcorder” button to start recording



NOTE: Camcorder button will change to Blue when recording is activated.

2. Press camcorder button again to save the video


3. Click return icon  to enter Device list






4. Press the list icon  to enter the main menu



5. Touch “local record” to locate the video on your smart phone. Press the snapshot will start play the video on your phone.



6. Press the edit icon  on top right corner, press snapshot to select the video.
7. Press the save icon  to save the video to your phone.





View snapshot at local files


1. Click return icon  to enter Device list



2. Press the list icon to enter the main menu




3. Touch "Local Album" to view the snapshot.
4. Press the edit icon  on top right corner, select the snapshot to view the picture.
5. Press the save icon  to save the snapshot to your phone.




Playback video on TF memory card (cameras with microSD only)


1. Touch home icon in the live view page.



2. Press “Remote playback” from the menu




3. The playback video will display. Press the button on right corner, you can select the time unit: h/m/s



NOTE: the footage block in Yellow is the video with motion detection. You need to enable the motion recording function in the camera to see the yellow block.


4. Press the speaker icon to activate the sound.



NOTE: Your camera must support audio and connects to audio pick up.


Download video from TF memory card (Cameras with microSD only)

1. In the live, press Home to enter “Menu”, press “Download”




2. Choose either download by file or by time



3. Click the “Download”  icon, the app start downloading by file

4. Click  icon twice to return to device list



5. Press the  icon to enter the main menu



6. Touch “local record” to view the download video.

Optional Receive the IP setting from your local network (DHCP)

If the IP cameras don't have corrected IP setting, especially DDNS, it will fail to receive the push message.

1. Touch home icon in the live view page.



2. Touch “set Network” from the menu, enter a new screen.
3. Slide the enable to right turn on DHCP. The camera will reboot and receive the IP setting from your local network.
4. Check the “set Network” again after 1-2 minutes, slide the enable to left if you want to fix the IP address.

Using CMS5 for PC or Mac

System Requirements

CPU	Core 2 Duo 3.0GHz
Operating System	Windows™ 8/7/Vista
Memory	2GB
Video	512 MB of video memory and above
Network (LAN)	10/100 Base-T Network
Network (WAN)	1 Mbps upstream High-speed Internet service is required to remotely connect to your system.

Installing Software


Download the latest version of the windows PC software using the link below.

<https://goo.gl/NHg7C3>

Network connection and settings

Connect to IP Camera

1. Click icon CMS5, a dialog will appear. Key in the username and password to enter Main.




NOTE: The default username and password of the software is "admin"

If you want to revise the login username and password of the software, go to the "Main" click "User Manager"




, change the new password.


2. In the "Main" , Click "Add Cameras" to enter a new screen.





3. Click "IPV4 search" button. The available devices will display on the left screen.



4. Mark the checkbox in front of the IP address, click "Add" button. The IP camera will move to right.



5. Click the pen icon  under “operation”, a new dialog pop up, name the camera, Click “OK” to save.



The 'Edit Device' dialog box contains the following fields:


- Device Name: Front door
- Group: Default Group
- Login Type: IP/Domain
- IP/Domain: 192.168.1.143
- Port: 34567
- UserName: admin
- Password: (empty)
- Protocol: GOLBONG

Buttons: OK, Cancel


NOTE: NO password required for camera/NVR in default. You can jump to page-11 to change camera's password.

NOTE: If you want to access the camera over internet, choose cloudID in “Login Type”

6. Once the software has connected the camera successfully, the “Status” will change to “connected”



The following devices have been added:

<input checked="" type="checkbox"/>	Name	CloudID	IP/Port	Group	Status	Operation
<input type="checkbox"/>	192.168.1....	0d13b1c2bd...	192.168.1.1...	Default Gr...	Connected	

Optional 1: How to add the cameras to CMS5 outside of LAN.


1. Click “Manual Add” button at the lower right corner. A new dialog appear.
2. Name the camera, choose the login type.

NOTE: if you didn't configure the port forwarding in your router, you properly need to choose the cloudID in login type.

3. Key in Static IP or cloudID

NOTE: You can mark down the cloudID when you connect the camera in the LAN

4. Key in password, and click “OK” to save.



Add Device

Device Name:

Group:

Login Type:

IP/Domain:

Port:


UserName:

Password:

Protocol:


Optional 2: How to configure the network setting of the camera manually.

1. In the "Main" , Click "Device Config", a new screen appear.




2. Select the camera from the list in the top left. All the icon will be activated with color

NOTE: If the icon remain black/white, check the connection status of your camera.



3. Click Network icon, a new screen will appear with "TCP/IP" setting.



4. Modify the IP setting. Click "OK" to save

Important: The DNS should be configured correctly, otherwise the cloud connection and email notification may not be working.

NOTE: If you don't know your network setting, mark "enable DHCP" to receive the IP setting from your local network. Click OK, the IP camera has to reboot to receive the correct IP setting from your local network.


The screenshot shows a configuration window with tabs for TCP/IP, DAS, Cloud, Email, FTP, DDNS, PPPOE, and RTSP. The TCP/IP tab is active. It contains the following fields and options:


- Interface:** A dropdown menu set to "Wired Interface".
- Enable DHCP:** An unchecked checkbox.
- IP:** A text field containing "192.168.1 .10".
- Submask:** A text field containing "255.255.255.0".
- Gateway:** A text field containing "192.168.1 .1".
- Primary DNS:** A text field containing "202.96 .128.86".
- Secondary DNS:** A text field containing "8 .8 .8 .8".
- RTSP Port:** A text field containing "34567".
- Http Port:** A text field containing "80".
- Onvif Port:** A text field containing "8899".
- MAC Address:** A text field containing "00:12:15:54:2f:7c".
- Enable High Speed Download:** An unchecked checkbox.
- Network Transmission Policy:** A dropdown menu set to "TransMis".

At the bottom right of the window are three buttons: "Apply", "OK", and "Cancel".


Live Video

Watch the live

1. In the "Main" , Click "Live" icon to enter live view interface.




2. Double click the camera in the devices list. CMS5 will start receiving the live.



NOTE: Double click the name again can close the video.


Digital ZOOM

1. Right the video you want to operate digital zoom on the screen, select "Digital Zoom"




2. Hold the left-button on mouse to selected area in red square.
3. Release the mouse to zoom in.
4. Right click mouse again, uncheck "digital zoom" to close the zoom operation.


Activate the audio

1. In the live, Click headset icon“


Important: You need to enable the audio in the “encode” in order to record the footage with audio.

Change the Password of the Camera

1. In the "Main" , click "Device Config". Enter "Tool Manager" on the right screen, A new screen appear.



2. In the top left menu, select the camera for which you want to change the password.
3. Click “User Manager” on the top screen.




3. Click "Modify Password". A new screen pop up. Enter the old password and your new password. Click “OK” to save.

Note: The default password is blank


Recording live to your computer

1. In the "Main" , Click "Record Settings" 



2. Mark the check box on the storage setting to select the storage disk from your PC computer.
3. Mark the checkbox to select "Record Schedule"
4. Mark the checkbox in front of "Enable Record", Click "Apply" button to Save.


NOTE: this is the switch button to turn on/off recording.



5. Return to the live interface, double click camera on the list, CMS5 will start recording from the live.



NOTE: the CMS5 only will start recording when it is receiving the live. Dis-connect the camera will turn off the recording.


NOTE: The camera icon will turn back/white  to blue  when CMS5 is recording.

6. Click camera icon  on top right windows to turn off the recording.




Playback the video on your computer

1. In the "Main" , Click "Playback" icon , a new screen appear.



2. Select the channel from the camera list in the upper right corner.



3. Select the time period in the lower right corner.


The screenshot shows a search interface with the following elements:


- Type:** A dropdown menu set to "All".
- Begin:** A text field containing "2017/5/9 0:00:00".
- End:** A text field containing "2017/5/9 23:59:59".
- Search:** A large button at the bottom.

NOTE: It only can search footage within a single day.


4. Click "Search". The search result will display as below.

Device Name	Channel Name	Record Type	Begin Time	End Time	Record Length	Operation
192.168.1.176	Channel1	Manual	2017-05-11 10:49:22	2017-05-11 11:13:21	23Minutes 745.8MB	


5. Select the footage from the list, click play button , the software will start playing.

NOTE: Click " " can locate the files in the PC computer.

6. Choose the "Time" over "File" at the left corner, the time frame will appear.



7. Move the mouse to the time frame, time will display in white. Click the mouse, the software will start playback the footage from this moment.




NOTE: the time in red is current playing time stamp.

Note : Mark the checkbox "Sync Play" can playback multi-channel at the same time


Recording live to TF memory card (cameras with microSD only)

Format TF memory card

1. In the "Main" , Enter "Device Config" and Click "Disk Manager" 




2. Select the memory disk from the list



NOTE: Only the model with TF memory card slot, and the TF memory card is installed will display memory information.

NOTE: Class 8 or higher TF memory card is required.

3. Click "Format" to erase all the data from the TF memory card.




Important: All the data will be erased with format operation.


NOTE: The TF memory card can not be viewed by windows PC directly.

Playback the video from TF memory card (cameras with microSD only)

1. In the "Main" , Click "Playback" .




- Click “Device” to playback the footage on TF memory card.



NOTE: If choose “Local”, The CMS5 will try to search the footage on the PC computer.


- Check and select the camera you want to playback.
- Select the time period in the lower right corner.




NOTE: It only can search footage within a single day.

- Click “Search”. The search result will display as below.


Device Name	Channel Name	Record Type	Begin Time	End Time	Record Length	Operation
192.168.1.12	Channel1	MotionAlarm	2017-05-11,10:48:36	2017-05-11,10:48:47	11Seconds 5.3MB	
192.168.1.12	Channel1	Regular	2017-05-11,10:48:47	2017-05-11,10:49:57	1Minutes 37.3MB	
192.168.1.12	Channel1	MotionAlarm	2017-05-11,10:49:57	2017-05-11,10:50:07	10Seconds 5.8MB	

- Select the footage from the list, click play button , the software will start play.

7. Choose the “Time” over “File” at the left corner, the time frame will appear.




8. Move the mouse to the time frame, time will display in white. Click the mouse, the software will start playback the footage from this moment.












NOTE: the time in red is current playing time stamp.

Download the video to your computer hard drive (cameras with microSD only)


1. Click the download icon  on the time frame, the software will start download the footage from the front device.

NOTE: the icon will change to red flag  when download is completed.

End Time	Record Length	Operation	
2017-05-11,10:55:53	10Seconds 4.7MB		
2017-05-11,11:02:41	6Minutes 212.4MB		
2017-05-11,11:02:53	12Seconds 5.5MB		
2017-05-11,11:07:58	5Minutes 150.5MB		

2. Click the red flag  to view the downloaded file in your PC computer.

3. Return to “Main” , Click the Backup icon .



4. Click the browser next to H.264 Record file and select the recording file from local PC

5. Select the save folder


- Click H264 to avi Convert to convert the file to avi format.




NOTE: You can find the download folder from “Main” -> System Config

Setting Camera Parameters


- In the "Main" , click “Device Config” icon
- Click “Camera param” 



- A new screen appear.



4. Day/Night Mode – Select “Color”, the camera will always stay on color.



NOTE: If the environment has significant street light at night, the camera can generate nice color night vision with color mode

5. Slow Shutter – Select “None” will erase motion blur, but low down the sensitivity.
6. Wide Dynamic – Turn on dynamic can improve the performance with strong constrat, but scarify the color reproduction and generate more noise in low light condition.
7. IR_CUT – select auto switch, the camera will switch to black and white and sense the infrared basing on the visible light illumination.



NOTE: Select auto switch can make the covert camera see infrared on the sense at night.


8. DNC Threshold – Change the threshold to switch between color and black/white.

NOTE: If the camera keep switch around between color and black/white, DNC threshold can improve the performance.


9. Mirror & Flip – Turn the image upside down. It can help deploy the camera from wall mount to ceiling mount.

Installing a new Firmware

1. In the "Main" , click icon “Batch Upgrade” 




2. Select the camera/NVR from the list



IMPORTANT: Different model could use different firmware, unless you are sure all the mode share the same firmware, don't check "Select All"

3. Click the Browser to find the firmware.
4. Click "Upgrade" to upload the firmware.

WARNING! DO NOT power off the camera until it shows upgrade successfully in the "Result"




Web Browser connection


Checking your web browser security level

When using the web browser interface, you can install ActiveX controls to connect and view video using Internet Explorer. However, if you cannot download data, such as video and images due to the increased security measure. you should check the security level of your PC so that you are able to interact with the cameras over the web and, if necessary, modify the Active X settings.

IMPORTANT: The ActiveX plugin only support 32bit version, choose the Internet Explorer over Internet Explorer (64 bit) in windows-7



1. In Internet Explorer click Internet Options on the Tools menu.
2. On the Security tab, click the zone to which you want to assign a web site under “Select a web content zone to specify its security settings”.
3. Click Custom Level.



4. Change the ActiveX controls and plug-ins options that are signed or marked as safe to Enable. Change the ActiveX controls and plug-ins options that are unsigned to Prompt or Disable. Click OK.




5. Click Apply in the Internet Options Security tab window.


Windows 7 or above users

Internet Explorer for Windows 7 or above operating systems have increased security measures to protect your PC from any malicious software being installed. To have complete functionality of the web browser interface with Windows 7, do the following to add the camera's IP address to your browser's list of trusted sites

1. Run the Browser interface as an administrator in your workstation
2. Click Tools, and then Internet Options
3. Click the Security tab, and then select the Trusted sites icon.
4. Click the Sites button.



5. Clear the “Require server verification (https:) for all sites in this zone box
6. Enter the IP address in the “Add this website to the zone” field.



7. Click Add, and then click Close
8. Click OK in the Internet Options dialog window.

Access the camera over internet

1. In the web browser enter the camera's IP address (default is 192.168.1.10), The Login dialog box appears.

NOTE: Ensure that the Active X controls are enabled.

2. Enter your user name and password.

Username: admin

Password: (no require)



3. Click Login. The web browser window appears in live view mode.



Note:

- To view setup videos for many of the steps outlined in this guide, go to <https://www.youtube.com/golbongtoday>
- This user manual is for reference only. Slight differences may be found in the user interface.
- All the designs and software here are subject to change without prior written notice.
- All trademarks and registered trademarks mentioned are the properties of their respective owners.

To contact GOLBONG support, please do one of the following:

- a. Visit <http://www.golbong.com/contact-us.asp> and use the email form
- b. or Email GOLBONG Customer Support: support@golbong.com

Copyright GOLBONG® 2017

